

Stackable Inverter (SI series)

By Power Master

**Sine Wave Inverter / ATS / Battery Charger /
Solar Charge controller (optional)**

**** More Inverters stackable ****

**** 3Phase connectable ****



USER MANUAL

CONTENTS

Introduction	4
Specification	7
Dimension	9
Chapter 1 Installation	11
1.1 Box Contents	11
1.2 Location	11
1.3 Requirements	11
1.4 Connection of Battery Cables	12
1.5 Connection of AC Cabling	12
1.6 Optional Connections.....	13
1.7 Grounding	14
1.8 Remote Control Panel (RCP-4)	14
Chapter 2 Settings.....	15
2.1 Four Control Modes Application	15
MODE 1: AC Power as Priority Support	15
MODE 2: AC Generator Support with Dynamic Power Shifting	18
MODE 3: Renewable Energy with Power Support	20
MODE 4: Renewable Energy with AC Charger Backup Support.....	23
Chapter 3 Wiring	25
3.1 Optional Fan Cover Application	25
3.2 Upper-Front Panel Display	26
3.3 Lower-Front Panel Display	29
3.4 Battery Connection	30
3.5 Parallel Connection Schematic	32
3.6 3-Phase Connection Schematic	33
3.7 3-Phase System 15 Modules	34
Capter 4 User Constants	35
4.1 Structure of User Constants	36
4.2 Operation Flow	40

Chapter 5 Constants List	48
U Group: Monitor.....	48
A Group: Initialize.....	49
B Group: General	49
C Group: Inverter.....	50
D Group: Charger	50
E Group: Aux-Relay	51
F Group: Solar Charger	56
O Group: Operator.....	56
 Chapter 6 Programming Constants	 62
A Group: Initialize.....	62
B Group: General	64
C Group: Inverter.....	71
D Group: Charger	73
E Group: Aux-Relay	76
O Group: Operator.....	82
U Group: Monitor.....	84
 Chapter 7 Trouble Shooting Table.....	 90

Introduction

General

- Feature

The “Stackable Inverter” is a 3 in 1 multi-function module unit – True Sine Wave Inverter built in programmable Battery Charger and Auto Transfer Switch (ATS). Besides these primary functions, however, the Stackable Inverter has several advanced features that provide a range of new applications as outlined below:

- Uninterrupted Power deliver

In the event of a grid failure, or shore or generator power being disconnected, the inverter within the Stackable Inverter is automatically activated and takes over supply to the connected loads. This happens so fast (less than 10 milliseconds) that computers and other electronic equipment will continue to operate without disruption.

- More inverters stackable

Virtually unlimited power thanks to parallel operation up to 5 units can operate in parallel to achieve higher power output. Five PM-3000SI-242 units, for example, provide 15kW of output power with 350A charging capacity.

- 3 Phase connectable

In addition to parallel connection, three units of the same model can be configured for three-phase output. But that’s not all: up to five sets of three units can be parallel connected for a huge 45kW inverter and 1050A charger!

- Power Control-Dealing with limited generator or shore side power

The “Stackable Inverter” is a very powerful battery charger. It will therefore draw a lot of current from the generator or shore side power. A maximum generator or shore current can be set (B2-05). The “Stackable Inverter” will then take account of other AC loads and use whatever is extra for charging thus preventing the generator or shore supply from overload.

- Power Assist-Boosting the capacity of shore or generator power

This feature takes the principle of Power Control to a farther dimension allowing the “Stackable Inverter” to supplement the capacity of the alternative source. Where peak power is so often required only for a limited period; it is possible to reduce the size of generator needed or conversely enable more to be achieved from typically limited shore connection. When the load reduces, the spare power is used to recharge the battery.

Battery Charger

- Adaptive 4-stage charge characteristic: Bulk-Absorption-Float-Equalize
The “Stackable Inverter” features a microprocessor controlled “adaptive” battery management system that can be preset to suit different types of batteries. The “adaptive” feature will automatically optimize the process relative to the way the battery is being used.
- The right amount of charge: Variable Absorption Time
When only shallow discharges occur (a yacht connected to shore power for example), the absorption time is kept in order to prevent overcharging of the battery. After a deep discharge, the absorption time is automatically increased to make sure that the battery is completely recharged.
- Preventing damage due to excessive gassing: The Battery Safe Mode
If, in order to quickly charge a battery, a high charge current in combination with a high absorption voltage has been chosen. The “Stackable Inverter” will prevent damage due to excessive gassing by automatically limiting the rate of voltage increase once the gassing voltage has been reached.
- Less maintenance and aging when the battery is not use: The Equalize Mode
The equalize mode kicks in whenever the battery has not been subjected to discharge during 24 hours. In the equalize mode, float voltage is reduced to 2.2V/cell (13.2V for 12V battery) to minimize gassing and corrosion of the positive plate. One a week, the voltage is raised back to absorption level to “equalize” the battery. This feature prevents stratification of the electrolyte and sulphation, a major cause of early battery failure.
- 2 outputs to charge 2 battery banks
The “Stackable Inverter” features 2 outputs, of which 1 can carry the full output current. The second output, limited to approximately 4A and with a slightly lower output voltage, is intended to top up a starter battery.
- To increase battery life: Temperature Compensation
Every “Stackable Inverter” comes with a battery temperature sensor (BTS-3) when connected, charge voltage will automatically decrease with increasing battery temperature. This feature is especially recommended for sealed batteries and/or when important fluctuation of battery temperature is expected.

- Battery Voltage Sense

In order to compensate for voltage loss due to cable resistance, the “Stackable Inverter” is provided with a voltage sense facility so that the battery always receives the correct charge voltage.

- Extensional Solar Charger

Stackable Inverter also provides the availability of up to 10 sets of Solar Charger, PM SCC 45A or PM SCC 60A (optional) to be used with solar panel to charge the battery. Stackable Inverter sends the 4-stage charging command to extensional Solar Charger via port C (Extension Port) for the best quality of solar charging.

Specification

MODEL	12 Volt System	PM-1500SI-12X (1)	PM-3000SI-12X (1)
	24 Volt System	PM-1500SI-24X	PM-3000SI-24X
	48 Volt System	PM-1500SI-48X	PM-3000SI-48X
GENERAL			
Ventilation		Forced cooling	Forced cooling
Temperature – Operation		-20°C ~ +70°C	-20°C ~ +70°C
– Storage		-25°C ~ +80°C	-25°C ~ +80°C
Protection			
a. Output short circuit		✓	✓
b. Over load		✓	✓
c. Battery voltage too high		✓	✓
d. Battery voltage too low		✓	✓
e. DC voltage ripple too high		✓	✓
f. Temperature Sensor			
Transformer		✓ (105°C)	✓ (105°C)
Electronic & Powerstage		✓ (70°C)	✓ (70°C)
BTS-3		✓ (50°C)	✓ (50°C)
Humidity		0~95% (non condensing)	0~95% (non condensing)
Power control Function		✓	✓
Power assist Function		✓	✓
Uninterrupted AC power		✓ (less than 10 msec)	✓ (less than 10 msec)
Adaptive 4-stage charge		✓	✓
Two output to charge 2 battery banks		✓	✓
Auxiliary Relay		X 3	X 3
Parallel operation		✓ (Max. 5 sets)	✓ (Max. 5 sets)
3-phase capacity		✓	✓
Battery voltage sensor		✓	✓
Battery Temperature sensor (BTS-3)		✓	✓
Remote control port		✓	✓
Extension Port (Port C)		✓	✓
INVERTER			
Input Voltage Range (VDC)		9.5 -16V / 19-32V / 38-64V	
Output Voltage (VAC)		185~240 VAC / 90~120 VAC	
Output Frequency		50Hz /60Hz ± 0.1%	
Output Waveform		Pure sinewave	


Output Voltage THD	< 5%	
Power Factor (All Loads)	✓	
No linger load, crest factor	3: 1	
Cont. Power Output (W) Under 70°C (cos θ=1.0)	1500W (No derate)	3000W (No derate)
Cont. Power Output (W) Over 70°C (cos θ=1.0)	0W (Shutdown)	0W (Shutdown)
Maximum Power (W)	3000W	6000W
Maximum Efficiency (%)	82/84/85	84/86/89
Zero-load Power (W)	12W	18W
CHARGER		
Input Voltage Range (VAC)	200~250 VAC / 100~125 VAC	
Input Frequency	45-55Hz /55-65 Hz	
Power Factor	1	
Charge Characteristic	4-stage adaptive / Bulk-Absorption-Float-Equalize	
Maximum DC Voltage Ripple (Vrms)	< 1.25 V	
Charge Current House Battery (A)	70A/40A/20A	140A/70A/40A
Charge Current Starter Battery (A)	4A	
Absorption Voltage Default (VDC)	14.4V / 28.8V / 57.6V	
Float voltage Default (VDC)	13.8V / 27.6V / 55.2V	
Equalize Voltage default (VDC)	13.2V / 26.4V / 52.8V	
Output Charge Voltage (min ~ max)	8V~16V / 11V~32V / 22V~64V	
Battery Temperature sensor	BTS-3	
AC INPUT SWITCH		
AC IN Terminal Circuit Breaker	15A (120V) /15A (230V)	30A (120V) /15A (220V)
Switch-over Time		
a. inverter to AC input	0 msec.	
b. AC input to inverter	0 msec.	
Detection Time AC Input Fault	4 ~10 msec.	
Trip Level AC Input to Inverter	90 VAC / 180 VAC	
Trip Level Inverter to AC Input	94 VAC / 187 VAC	
Min.~ Max. Frequency Range	45-55 Hz / 55-65 Hz	
MECHANICAL		
Cabinet / Protecting Class	Aluminum / IP20	
Dimension (HXWXD)	362 x 258 x 370 mm	424 x 258 x 370 mm
Weight (kgs)	30 kgs	35 kgs

(1) X should be 1, output voltage = 90~120 VAC or 2, output voltage = 185~240 VAC


Dimension

PM-1500SI-12/24

Unit: mm




Installation Holes




PM-3000SI-12/24

Unit: mm



Installation Holes



Chapter 1 Installation



This product should be installed by a qualified electrician.

1.1 Box Contents

- Stackable Inverter
- USER MANUAL
- Bag Containing connection items, ie:
 - Battery Temperature Sensor (BTS-03)
 - Four M8 nuts (including spring washers)
 - Four terminals and casing

1.2 Location

The product must be installed in a dry and well-ventilated area, as close as possible to batteries. There should be a clear space of at least 20 cm around the appliance for cooling.



Excessively high ambient temperature will result in the following

- Reduced service life
- Reduced charge current
- Reduced peak capacity or shutdown of the inverter

Never position the appliance directly above the batteries.

The product is suitable for wall mounting. The back and the bottom of the enclosure has holes for wall mounting purposes, see Page 9 and 10.

The appliance can be mounted horizontally as well as vertically; vertical mounting is preferable. Te vertical position offers optimum cooling.



The interior of the product must remain accessible after installation. Ensure the AC and DC input cables are fitted with fuses and circuit breakers. Try and keep the distance between the product and battery to a minimum in order to minimize cable voltage losses.



For safety purpose, this product should be installed in a heat-resistant environment if it is used with equipment where a substantial amount of power is to be converted. You should prevent the presence of e.g. chemicals, synthetic components, curtains or textiles, etc. in the immediate vicinity.

1.3 Requirements

- Screwdrivers for removing the lower-front panel and connecting AC loads.
- 2 battery cables (maximum length 6 meters)

- Including battery terminals and cable ends.
- Insulated box spanner (13 mm) for securing the DC terminal nuts.
- Three-wire cable for AC cabling.

1.4 Connection of Battery Cables

In order to fully utilize the full capacity of the product, batteries with sufficient capacity and battery cables with sufficient cross section should be used, please see table:

Model Item	PM-1500SI-12X	PM-1500SI-24X	PM-3000SI-12X	PM-3000SI-24X
Recommended battery capacity (Ah)	200~700	100~400	400~1200	200~700
Recommended cross section (mm ²)(0~6m)	50 mm ²	38 mm ²	80 mm ²	50 mm ²

Remark: Internal resistance is the important factor when working with low capacity batteries. Consult your supplier.

Procedure:

Proceed as follows to connect the battery cables:



Use an insulated box spanner in order to avoid shorting the battery.

Avoid shorting the battery cables:

- Undo the four screws at the lower-front panel of the enclosure and remove the panel.
- Connect the battery cable: the + (red) on the right and the – (black) on the left. Please see page 30 and 31.
- Don't reverse the (+) and (-) of the battery. This may cause internal damage.
- Tighten the connections after positioning the fastening items supplied with product.
- Secure the nuts tightly in order to reduce the contact resistance as much as possible.

1.5 Connection of AC Cabling



The enclosure must be grounded for safety purpose. An earth screw has been fitted at the bottom side of the enclosure.

The terminal block can be found at lower-front panel of the enclosure: The shore or mains (AC IN) cable must be connected to AC IN terminals, use a three-wire cable and a cross section of 4~10 mm².

Procedure:

Proceed as follows to connect the AC cables.

- The AC output cable can be connected directly to terminal block containing the word

“AC OUT”. The terminal points are indicated clearly. From left to right: “G” (earth), “N” (neutral), and “L” (phase).

- The AC input cable can be connected to the terminal block containing the word “AC IN”, the terminal points are indicated clearly from left to right “L” (phase), “N” (neutral), and “G” (earth).



The current which is switched through to the output (AC OUT) is not fused. External fuses or current limiters have to be installed.

1.6 Optional Connections

A number of operational connections are possible:

1.6.1 Second Battery

The “Stackable Inverter” has a connection for charging a starter battery.

For connection, see page 29.

1.6.2 Voltage Sense

Two sense wires may be connected to compensate possible battery cable losses during charging. Use wires of at least 0.75 mm². For connection, see page 29.

1.6.3 Battery Temperature Sensor (BTS-3)

The battery temperature sensor supplied with the product may be used for temperature compensated charging, see page 29.

The sensor is insulated and must be mounted on the batteries minus pole.

1.6.4 3 Sets of Auxiliary Relay (RY1, RY2, RY3) Output

The “Stackable Inverter” provides 3 sets of Auxiliary Relays for users to connect to other appliances or to output the alarm signals. 3 sets of relays can be programmed for respective function. (E Group Constants) and can be practically applied which is one of the greatest features.

1.6.5 Parallel Connection

The product can be connected in parallel using several identical modules, please see page 32. The batteries must be connected in accordance with page 32. This requires interconnecting the products with the package of a special box, parallel box, to be supplied by factory in conjunction with a connection diagram.

Parallel connection requires compliance with the following conditions:

1. No more than 5 units should be connected in parallel.
2. Only identical models should be connected in parallel.
3. Ensure sufficient battery capacity is available.
4. The prescribed cable cross sections (between battery and distribution point) must be multiplied with the number of appliances to be connected in parallel.
5. Position the products close to each other but ensure there is adequate clearance for ventilation minimum 20 cm. For better ventilation, please install the fan cover

(optional).

6. The BTS, voltage sensor and remote control panel (RCP) must be connected to Master.
7. The cables for each appliance must be equal in length (AC and DC)

1.6.6 3-Phase Operation

The product can also be used in a 3-phase system, see page 33. The batteries must be connected in accordance with page 33. The following condition conditions should be complied with in the case of 3-1phase operation:

1. Only identical models should be used.
2. Ensure sufficient battery capacity is available.
3. Position the products close to each other but ensure there is adequate clearance for ventilation minimum 20 cm.
(For the better ventilation environment, it is highly recommended to install the fan cover in the air-in on the right side of Stackable Inverter.
4. The BTS, voltage sensor should preferably be connected all three units (1 Master unit and 2 Follower units).
5. Only a single remote control can be connected.

1.7 Grounding

When the input voltage of the Stackable Inverter is not switched through, the neutral of “AC OUT” is connected to ground by means of a relay. This function can be disabled by constant B2-07 (B2-07=0 Disconnect)

1.8 Remote Control Panel (RCP-4)

The product can be operated remotely from remote port with the aid of a remote control panel. For connection of a remote control panel, see page 28.

Note: The display panel and operation flow of the remote control panel is exactly the same as the upper-front display panel.

Chapter 2 Settings

- Settings may only be changed by a qualified engineer.
- Carefully read the user manual before any change is made.
- When setting the charger, all connections to the battery must be disconnected from the Stackable Inverter.
- Do not use non-rechargeable batteries.
- Batteries should be placed in a dry and well-ventilated area during charging.
- The product default settings are for charging gel batteries. For the recommended battery voltage initial settings, see D1 (Charger) Group parameters.


2.1 Four Control Modes Applications

MODE 1: AC Power as Priority Support (Example of PM-3000SI-242)

When Stackable Inverter enters to MODE 1, B2-09 (AC IN DynaCur Limit)=0 (Disable) and the value of B2-18 (MODE1: ACINCurrent Lmt) will be loaded to B2-05.

1. INVERTER Mode:

- When AC IN=0 A, AC OUT load is completely supplied by INVERTER. It goes to the inverter mode.




2. Power Control Mode (a)

- In this example:

All AC loads are off, with the “Stackable Inverter” constant B2-05=5A (AC IN Current Limit),


the AC CHARGER will not take more than 5A with limits to battery charge current to 75A.



3. Power Control Mode (b)


- Now some small loads are switched on and load increase to 3A. Only $5-3=2A$ is left to charge the batteries and charge current is reduced to about 30A.

※ Note: Shore current is automatically limited to 5A and the AC input circuit breaker will not trip!




4. Power Control Mode (c)

- The load is switched on and current consumption increase to 5A. Nothing is left to charge the battery.
- The charge current is automatically reduced to 0A, and the AC input circuit breaker does not trip!



5. Power Assist Mode

- And now the other load adds and switches on and the current increases to 11A. This is where Power Assist is needed.
- The bidirectional converter starts operating as inverter to add 6A to the 5A that is available from the shore-side: Total $6+5=11$ A, and no overload on the AC supply.
- As soon as the load reduces to less than 5A, any current that is left over will be used to recharge the battery.




MODE 2: AC Generator Support with Dynmaic Power Shifting

(Example of PM-3000SI-242)

When Stackable Inverter enters to MODE 2, B2-09(AC IN DynaCur Limit)=1 (Enable) and the value of B2-21 (MODE 2: ACINCurrent Lmt) will be loaded to B2-05.

1. INVERTER Mode:

- When AC IN=0 A, AC OUT load is completely supplied by INVERTER. It goes to the inverter mode.




2. Power Control Mode (a)

- In this example:


All AC loads are off, with the “Stackable Inverter” constant B2-05=5A (AC IN Current Limit),

the AC CHARGER will not take more than 5A with limits to battery charge current to 75A.




3. Power Control Mode (b)

- Now some small loads are switched on and load increase to 3A. Only $5-3=2A$ is left to charge the batteries and charge current is reduced to about 30A.
- ※ Note: Shore current is automatically limited to 5A and the AC input circuit breaker will not trip!



4. Power Control Mode (c)

- The load is switched on and current consumption increase to 5A. Nothing is left to charge the battery.
- The charge current is automatically reduced to 0A, and the AC input circuit breaker does not trip!




MODE 3: Renewable Energy with Power Support

When Stackable Inverter enters to MODE 3, B2-09(AC IN DynaCur Limit)=0 (Disable) and the value of B2-20 (MODE3: ACINCurrent Lmt) will be loaded to B2-05.


1. INVERTER Mode:

- When the battery voltage is not lower than (B2-14) voltage value, inverter mode takes priority to supply voltage to AC OUT for load consumption.
(INVERTER ON+ ATS OFF + AC CHARGER OFF)




2. Power Control Mode

- When AC IN power is ready, INVERTER is active and battery voltage is lower than B2-14 voltage value and longer than the second time set in B2-15, ATS will be switched on to ensure AC OUT to continuously supply the load. At the moment, AC OUT will be supplied by AC IN power. At the same time, the battery is charged from AC IN power (AC CHARGER OFF) only by other wind charger or DC generator charger.
- The difference between MODE 3 and MODE 4 is that in MODE 3, when AC IN power is ready, AC CHARGER is off and the battery is charged by other renewable energy. This is why MODE 3 is called Green Power as Priority Support Mode
(INVERTER OFF+ ATS ON + AC CHARGER OFF)




3. Power Assist Mode

- And now the other load adds and the current increases to 11A. This is where Power Assist function is needed!
(ATS ON + AC CHARGER OFF + INVERTER ON + Power Assist Mode ON)
- As soon as the load reduces to less than 5A, power assist function stops.



4. “INVERTER Mode” Repeat

- When the battery is recharged by other renewable energy source, battery voltage is higher than B2-14 voltage value and longer than second time set in B2-15, inverter mode takes priority to supply voltage to AC OUT again for load consumption.




MODE 4: Renewable Energy with AC Charger Backup Support

When Stackable Inverter enters to MODE 4, B2-09(AC IN DynaCur Limit)=0 (Disable) and the value of B2-19 (MODE4: ACINCurrent Lmt)will be loaded to B2-05.


1. INVERTER Mode:

- When the battery voltage is not lower than (B2-10) voltage value, inverter mode takes priority to supply voltage to AC OUT for load consumption.
(INVERTER ON+ ATS OFF + AC CHARGER OFF)




2. Power Control Mode:

- When AC IN power is ready, INVERTER is active and battery is about to be exhausted, battery voltage is lower than B2-10 voltage value and longer than the second time set in B2-11, ATS will be switched on to ensure AC OUT to continuously the load. At the moment, AC OUT will be supplied by AC IN power. At the same time, the power control mode is active and will supply the extra AC IN power to charge the battery!
(INVERTER OFF + ATS ON + AC CHARGER ON + Power Control Mode ON)




3. Power Assist Mode

- And now the other load adds and the current increases to 11A. This is where Power Assist function is needed!
(ATS ON + AC CHARGER OFF + INVERTER ON + Power Assist Mode ON)
- As soon as the load reduces to less than 5A, any current that is left over will be used to recharge the battery.



4. “INVERTER Mode” Repeat

- When the battery voltage is higher than B2-12 voltage value and longer than second time set in B2-15, inverter mode takes priority to supply voltage to AC OUT again for load consumption.



Chapter 3 Wiring

3.1 Optional Fan Cover Application

3.1.1 Standard Single Unit

When the unit is installed in an environment with good ventilation, the fan cover is not needed.



3.1.2 Single Unit Installed

When the unit is installed nearby wall side which blocks the airflow coming to the unit, the fan cover is needed.




3.1.3 Multiple and 3-Phase Application

When there is more than one Stackable Inverter in parallel connection or 3-phase connection, the optional accessory, fan covers, are highly recommended to be installed for each Stackable Inverter to have better ventilation in cooling down the temperature.



3.2 Upper-Front Panel Display



Push Buttons

Push buttons	Name	Description	
PB1	RUN/STOP	Stackable Inverter RUN/STOP key	
PB2	MODE 1	AC Power as Priority Support	Before changing from one mode to another, it has to stop running and be in STOP mode.
PB3	MODE 2	AC Generator Support with Dynamic Power Shirting	
PB4	MODE 3	Renewable Energy with Power Support	
PB5	MODE 4	Renewable Energy with AC Charger Backup Support	
PB6	DSPL	Multi-display select key	
PB7	ENTER	Data write-in key	
PB8	UP (△)	△ Increment key	Press △ and ▽ keys at the same time to enable the cursor to move to the left digit from the current digit.
PB9	DOWN (▽)	▽ Decrement key	


Note:

1. When pressing RUN/STOP key, the holding time to remain on the key has to be at least 2 seconds (initial setting) to activate the RUN or STOP function in order to avoid any accidental pressing on the RUN/STOP key. The second time can be adjusted in RUN/STOP KeyHoldTime (O2-07).
2. When changing any of four modes to another mode, Stackable Inverter has to STOP and then press the desired mode key. When pressing MODE 1 or MODE 2 or MODE 3 or MODE 4 key, the holding time has to remain on the key has to be at least 5 seconds (initial setting) to activate the mode change in order to avoid any accidental pressing on the mode keys. The second time can be adjusted in MODE Key Hold Time (O2-06).
3. The beep sound of key pressing can be selected to be enabled or disabled in Key Pressed Beep Sel (O2-01)
4. When all the keys are not pressed at all for a certain time (O1-02), it goes to idle mode. Once any key is pressed, the display will return to the LCD monitor selection value set in constant O1-01.
5. When all the keys are not pressed at all for a certain time (O2-09), all the LCD Display and LED Indicators are not active but RUN/STOP indicator remains active. The display idle function can save the display power.
6. Press \triangle key to increase the setting value and ∇ key to decrease the setting value. Press \triangle and ∇ keys at the same time to enable the cursor to move to the left digit from the current digit. For example, if the current digit stays in decimal, press \triangle and ∇ at the same time for the digit to move to centesimal.

LED Indicators

LED	Name	L ED ON	LED OFF
1	AC IN	1. Input voltage normal, and position > "transfer Voltage Level" (150VAC~240VAC) 2. Input voltage frequency range in between(45~65Hz)	No input power
2	AC CHARGER	Green : Battery charger is working.	-----
3	SOLAR PANEL	Solar module is delivering energy.	1. Solar module aren't connect or 2. Day or Night / (cloudy day)
4	SOLAR CHARGER	Solar charger is working	No external solar charger is connected.
5	AC OUT	There is voltage at the "AC OUT" terminal.	-----
6	INVERTER	Green : Inverter is working.	-----
7	BATTERY	FLOAT or ABSOR. Or BULK charge state of battery.	-----
8	ATS	Green : ATS switch is active AC IN voltage is being sent directly to AC OUT terminal	-----
9	RUN/STOP	Green : Stackable Inverter turn on. Red : Stackable Inverter turn off.	-----
		NOTE: Green Blink : Auto-Restart is in use	
10	COM./ERR.	Remote control port in communication/in error	

3.3 Lower-Front Panel Connection




Connections / Lower-Front side


A	PORT A (IN)	Connections for parallel power/3-phase power
B	PORT B (OUT)	Connections for parallel power/3-phase power
C	PORT C (EXT)	Connections for external solar/wind modules
D	CHARGE	Connecting terminal for starting battery of 4A
E	BTS (Battery temp. sensor)	Connecting terminal for temperature sensor.
F	Vsens +/- (Battery Voltage Sense)	Connecting terminal for Battery Voltage feedback
G	RY1 contact	Connecting terminal for auxiliary contact 1.
H	RY2 contact	Connecting terminal for auxiliary contact 2.
I	RY3 contact	Connecting terminal for auxiliary contact 3.
J	AC OUT L	Connecting terminal for AC output Line
K	AC OUT N	Connecting terminal for AC output Neutral
L	AC OUT G	Connecting terminal for AC output Ground
M	AC IN G	Connecting terminal for AC input Ground
N	AC IN N	Connecting terminal for AC input Neutral
O	AC IN L	Connecting terminal for AC input Line
P	Battery POS+/ NEG-	Battery cables.

3.4 Battery Connection


3.4.1 Star Connection Schematic



3.4.2 Rail Connection Schematic




3.5 Parallel Connection Schematic



For the MASTER, constant B2-05 and B3-01 must be set.
For the SLAVE 1 and 2, constant settings are not required.

3.6 3-Phase Connection Schematic



MASTER constants setting:

B4-01=1
B4-02=1
B4-03=0


FOLLOWER 1 constants setting:

B4-01=1
B4-02=0
B4-03=0

FOLLOWER 2 constants setting:

B4-01=1
B4-02=0
B4-03=0

3.7 3-Phase System 15 Modules



For the settings of MASTER, FOLLOWERS and SLAVES, see 3.5 and 3.6

Chapter 4 User Constants

There are four “Macro Function” under the main menu of the “Stackable Inverter” and they are “Operation”, “Initialize”, “Programming” and “Modified Constants”. The functions and their contents are as below.

Function	Content
Operation	“Stackable Inverter” can monitor AC IN voltage and current, AC OUT voltage and current, battery voltage, battery current and ripple voltage in charging and discharging battery and other extension modules status. This is U (Monitor Group) constants.
Initialize	Operation Condition Setting Group A (Initialize) Group: Multi-language setting, constants initialization setting and constants modification allowed/prohibited setting.
Programming	Constant groups to program (modify) all the constants: B (General) Group, C (INVERTER) Group, D (AC CHARGER) Group, E (Aux-relay) Group F (Solar charger) Group, G (DC to DC charger) Group H (DC load control) Group and O (Operator) Group
Modified Constants	Operating the read-out and modification of the constants group setting which are different from initial setting. Users can program and modify constants

Operation of “Macro Function”


On any display screen, pressing DSPL key could have the effect just like ESC key to enable the display screen go back to previous any of four “Macro Function”


*** Main Menu ***
XXXXXXXX


(XXXXXXXX can be either Operation or Initialize or Programming or Modified Constants.)


And continue to press DSPL key to select “Macro Function”

4.1 The following is the structure of user constants.











4.2 The following is the operation flow.


Main Menu




Main Menu : Operation




Main Menu : Initialize




Main Menu : Programing - Function B1 - B1-01




Main Menu : Programing - Function B2 - B2-01




Main Menu : Programming - Function B3 - B3-01




Main Menu : Programming - Function B4 - B4-01




Main Menu : Programing - Function C1 - C1-01




Main Menu : Programing - Function D1 - D1-01




Main Menu : Programming - Group E - Function E1 - E1-01




Main Menu : Programming - Group E - Function E2 - E2-01




Main Menu : Programing - Function F1 - F1-01



Main Menu : Programing - Group O - Function O1 - O1-01



Main Menu : Programing - Group O - Function O2 - O2-01



Chapter 5 Constants List

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Operation	U	Monitor	U1	Monitor	U1-01	AC IN Voltage	—	0.1V	—		84
					U1-02	AC IN Current	—	0.1A	—		84
					U1-03	AC OUT Voltage	—	0.1V	—		84
					U1-04	AC OUT Current	—	0.1A	—		84
					U1-05	Battery Voltage	—	0.1V	—		84
					U1-06	Battery Ripple Volt	—	0.1V	—		84
					U1-07	Battery Current	—	0.1A	—		84
					U1-08	Control Mode	—	—	—		84
					U1-09	Operation Status	—	—	—	NOTE 1	85
					U1-10	Aux-Relay Status	—	—	—	NOTE 2	85
					U1-11	Elapsed Time	—	1hour	—		85
					U1-12	Bat.Temp.Sensor	—	1°C	—		85
					U1-13	CPU ID 1	—	—	—		85
					U1-14	CPU ID 2	—	—	—		85
					U1-15	Solar Charger Status	—	—	—	NOTE 5	85
					U1-16	Solar Supply Current	—	0.1A	—	NOTE 5	85
					U1-17	Solar Supply Power	—	1W	—	NOTE 5	86
					U1-18	Solar Amp-Hours	—	0.1AH	—	NOTE 5	86
					U1-19	Solar Total Amp-Hours	—	0.1AH	—	NOTE 5	86
			U2	Fault Trace	U2-01	Current Fault	—	—	—		86
					U2-02	Last Fault	—	—	—		86
					U2-03	AC IN Voltage	—	0.1V	—		86
					U2-04	AC IN Current	—	0.1A	—		86
					U2-05	AC OUT Voltage	—	0.1V	—		86
					U2-06	AC OUT Current	—	0.1A	—		87
					U2-07	Battery Voltage	—	0.1V	—		87
					U2-08	Battery Ripple Volt	—	0.1V	—		87
					U2-09	Battery Current	—	0.1A	—		87
					U2-10	Control Mode	—	—	—		87
					U2-11	Operation Status	—	—	—	NOTE 1	87
					U2-12	Aux-Relay Status	—	—	—	NOTE 2	87
					U2-13	Elapsed Time	—	1hour	—		87
					U2-14	Solar Charger Status	—	—	—	NOTE 5	88

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Operation	U	Monitor	U2	Fault Trace	U2-15	Solar Charge Current	—	0.1A	—	NOTE 5	88
					U2-16	Solar Supply Power	—	1W	—	NOTE 5	88
					U2-17	Solar : Amp-Hours	—	1AH	—	NOTE 5	88
					U2-18	Solar:TotalAmp-Hours	—	1AH	—	NOTE 5	88
					U2-26	Bat.Temp. Sensor	—	1°C	—		88
			U3	Fault History	U3-01	Last Fault	—	—	—		88
					U3-02	Fault Message 2	—	—	—		88
					U3-03	Fault Message 3	—	—	—		89
					U3-04	Fault Message 4	—	—	—		89
					U3-05	Elapsed Time 1	—	1hour	—		89
					U3-06	Elapsed Time 2	—	1hour	—		89
					U3-07	Elapsed Time 3	—	1hour	—		89
					U3-08	Elapsed Time 4	—	1hour	—		89
Initialize	A	Initialize	A1	Initialize	A1-01	Access Level	0~1	1	1	0: Operation Only 1: Constant Set	62
					A1-02	Select Language	—	—	0	0:English	62
					A1-03	Init Parameters	0~1	1	0	0: No Initialize 1:Default Setting	62
					A1-04	Password 1	0~999	1	0		63
Programm- ing	B	General	B1	Output Frequency	B1-01	Output Frequency	0~1	1	0	0: 50 Hz 1:60 Hz	64
			B2	Auto Transfer Switch	B2-01	AC IN Low Disconnect	NOTE 3	1V	NOTE 3		64
					B2-02	AC IN Low Connect	NOTE 3	1V	NOTE 3		64
					B2-03	AC IN High Connect	NOTE 3	1V	NOTE 3		65
					B2-04	AC IN High Disconnect	NOTE 3	1V	NOTE 3		65
					B2-05	AC IN Current Limit	NOTE 3	0.1A	NOTE 3		65
					B2-06	AC IN Waveform Check	0~1	1	1	0: Ignore 1: Active	65
					B2-07	Ground Relay	0~1	1	1	0: Disconnect 1: Connect	66
					B2-08	ACIN Frequency Range	0~1	1	1	0:50/60Hz+~5Hz 1:45Hz~65Hz	66
					B2-09	AC IN DynaCur Limit	0~1	1	0	0: Normal 1:Dynamic	66

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programm- ing	B	General	B2	Auto Transfer Switch	B2-10	MODE 4: BatLo?V ATS ON	0~32.00 0~16.00	0.01V	23.5V 11.75V		67
					B2-11	MODE 4: BatLo?S ATS ON	0~255	1 sec	10 sec		67
					B2-12	MODE 4: BatHi?V ATSOFF	0~32.0 0~16.0	0.01V	28.8V 14.4V		67
					B2-13	MODE 4: BatHi?S ATSOFF	0~255	1 sec	60 sec		67
					B2-14	MODE 3: BatLo?V ATS ON	0~32.0 0~16.0	0.01V	23.5V 11.75V		67
					B2-15	MODE 3: BatLo?S ATS ON	0~255	1 sec	10 sec		67
					B2-16	MODE 3: BatHi?V ATSOFF	0~32.0 0~16.0	0.01V	28.8V 14.4V		67
					B2-17	MODE 3: BatHi?S ATSOFF	0~255	1 sec	60 sec		67
					B2-18	MODE1:ACINCurrent Lmt	NOTE 3	0.1A	NOTE 3		68
					B2-19	MODE2:ACINCurrent Lmt	NOTE 3	0.1A	NOTE 3		68
					B2-20	MODE3:ACINCurrent Lmt	NOTE 3	0.1A	NOTE 3		69
					B2-21	MODE4:ACINCurrent Lmt	NOTE 3	0.1A	NOTE 3		69
			B3	Parallel	B3-01	Number of Slave	0~4	1	0		69
			B4	2-3 Phase	B4-01	2-3 Phase Connection	0~1	1	0	0:Disable 1:Enable	69
					B4-02	2-3 Phase Master	0~1	1	0	0:Slave 1:Master	70
					B4-03	2-3 Phase Type	0~2	1	0	0:3 phase 1: Split phase 180 2: Two Leg phase 120	70
	C	Inverter	C1	Inverter	C1-01	Inverter Out Voltage	NOTE 3	1V	NOTE 3		71
					C1-02	Bat Low ? V Shut-down	NOTE 3	0.01V	NOTE 3		71
					C1-03	Bat Low ? V Restart	NOTE 3	0.01V	NOTE 3		71

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programming	C	Inverter	C1	Inverter	C1-05	Power Assist Select	0~1	1	1	0: Disable 1: Enable	71
					C1-06	Power Assist Level	1.0~3.5	0.1	2.0		72
	D	Charger	D1	Charger	D1-02	Charge Curve	1~3	1	3	1: Fixed 2: Adaptive 3: Adaptive+safe	73
					D1-03	Absorption Voltage	NOTE 3	0.01V	NOTE 3		74
					D1-04	Rep-Absorption Time	1~72	0.25hour	4	4x0.25=1 hour	74
					D1-05	Rep-Abs Interval	1~180	0.25day	28	28x0.25=7day	74
					D1-06	Max. Absorption Time	1~8	1hour	4hour		74
					D1-07	Float Voltage	NOTE 3	0.01V	NOTE 3		74
					D1-08	Charge Current	NOTE 3	1A	NOTE 3		74
					D1-09	Stop After 10Hr Bulk	0~1	1	1	0:Disable 1:Enable	74
					D1-10	Equalize Mode Select	0~1	1	1	0:Disable 1:Enable	75
	E	Aux-Relay	E1	Set Aux-Relay 1 ON	E1-01	LOAD Higher than ? A	NOTE 3	0.01A	NOTE 3		76
					E1-02	LOAD Higher for ? sec	0~255	1sec	0sec		76
					E1-03	Udc Lower than ? V	NOTE 3	0.01V	NOTE 3		76
					E1-04	Udc Lower for ? sec	0~255	1sec	0sec		76
					E1-05	Udc Higher than ? V	NOTE 3	0.01V	NOTE 3		76
					E1-06	Udc Higher for ? sec	0~255	1sec	0sec		76
					E1-07	Not Charge for ? sec	0~255	1sec	0sec		76
					E1-08	Fan On for ? sec	0~255	1sec	0sec		76
					E1-09	When bulk Protection	0~1	1	0	0:Disable 1:Enable	77
					E1-10	System Fault Occurs	0~1	1	0	0:Disable 1:Enable	77
					E1-11	Temp. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	77
					E1-12	Temp. Alarm for ?sec	0~255	1sec	0sec		77

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programm- ing	E	Aux-Relay	E1	Set Aux- Relay 1 ON	E1-13	Low Batt. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	77
					E1-14	Low Batt. for ? sec	0~255	1sec	0sec		77
					E1-15	Overload Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	77
					E1-16	OL Alarm for ? sec	0~255	1sec	0sec		77
					E1-17	Udc Ripple Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	77
					E1-18	UdcRipAlarm for ? sec	0~255	1sec	0sec		77
	E	Aux-Relay	E2	Set Aux- Relay 1 OFF	E2-01	Load Lower than ? A	NOTE 3	0.01A	NOTE 3		78
					E2-02	Load Lower for ? sec	0~255	1sec	0sec		78
					E2-03	Udc Lower than ? V	NOTE 3	0.01V	NOTE 3		78
					E2-04	Udc Lower for ? sec	0~255	1sec	0sec		78
					E2-05	Udc Higher than ? V	NOTE 3	0.01V	NOTE 3		78
					E2-06	Udc Higher for ? sec	0~255	1sec	0sec		78
					E2-07	Charging for ? sec	0~255	1sec	0sec		78
					E2-08	Fan Off for ? sec	0~255	1sec	0sec		79
					E2-09	Charge Finished ? Min	0~1000	1min	0		79
					E2-10	RY1 not ON for ? mins	0~1000	1min	0		79
					E2-11	AC IN Loss for ? sec	0~255	1sec	0sec		79
					E2-12	No Temp. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	79
					E2-13	No Temp. Alarm ? sec	0~255	1sec	0sec		79
					E2-14	No Low Bat. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E2-15	No Low Bat for ? sec	0~255	1sec	0sec		80
					E2-16	No OL Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E2-17	No OL Alarm for ? sec	0~255	1sec	0sec		80
					E2-18	No UdcRipple Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E2-19	No UdcRipple Alarm ?sec	0~255	1sec	0sec		80

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programm- ing	E	Aux-Relay	E3	Set Aux- Relay 2 ON	E3-01	Load Higher than ? A	NOTE 3	0.01A	NOTE 3		80
					E3-02	Load Higher for ?sec	0~255	1sec	0sec		80
					E3-03	Udc Lower than ? V	NOTE 3	0.01V	NOTE 3		80
					E3-04	Udc Lower for ? sec	0~255	1sec	0sec		80
					E3-05	Udc Higher than ? V	NOTE 3	0.01V	NOTE 3		80
					E3-06	Udc Higher for ? sec	0~255	1sec	0sec		80
					E3-07	Not Charge for ? sec	0~255	1sec	0sec		80
					E3-08	Fan On for ? sec	0~255	1sec	0sec		80
					E3-09	When bulk Protection	0~1	1	0	0:Disable 1:Enable	80
					E3-10	System Fault Occurs	0~1	1	0	0:Disable 1:Enable	80
					E3-11	Temp. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E3-12	Temp. Alarm for ?sec	0~255	1sec	0sec		80
					E3-13	Low Batt. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E3-14	Low Batt. for ? sec	0~255	1sec	0sec		80
					E3-15	Overload Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E3-16	OL Alarm for ? sec	0~255	1sec	0sec		80
					E3-17	Udc Ripple Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E3-18	UdcRipAlarm for ?sec	0~255	1sec	0sec		80
			E4	Set Aux- Relay 2 OFF	E4-01	Load Lower than ? A	NOTE 3	0.01A	NOTE 3		80
					E4-02	Load Lower for ? sec	0~255	1sec	0sec		80
					E4-03	Udc Lower than ? V	NOTE 3	0.01V	NOTE 3		80
					E4-04	Udc Lower for ? sec	0~255	1sec	0sec		80
					E4-05	Udc Higher than ? V	NOTE 3	0.01V	NOTE 3		80
					E4-06	Udc Higher for ? sec	0~255	1sec	0sec		80
					E4-07	Charging for ? sec	0~255	1sec	0sec		80
					E4-08	Fan OFF for ? sec	0~255	1sec	0sec		80
					E4-09	Charge Finished ?Min	0~1000	1min	0		80
					E4-10	RY2 not ON for ?mins	0~1000	1min	0		80

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programm- ing	E	Aux-Relay	E4	Set Aux- Relay 2 OFF	E4-11	AC IN Loss for ?sec	0~255	1sec	0sec		80
					E4-12	No Temp. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E4-13	No Temp. Alarm ? sec	0~255	1sec	0sec		80
					E4-14	No Low Bat. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E4-15	No Low Bat for ? sec	0~255	1sec	0sec		80
					E4-16	No OL Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E4-17	No OL Alarm for ? sec	0~255	1sec	0sec		80
					E4-18	No UdcRipple Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E4-19	No UdcRipple Alarm ?sec	0~255	1sec	0sec		80
			E5	Set Aux- Relay 3 ON	E5-01	Load Higher than ? A	NOTE 3	0.01A	NOTE 3		80
					E5-02	Load Higher for ?sec	0~255	1sec	0sec		80
					E5-03	Udc Lower than ? V	NOTE 3	0.01V	NOTE 3		80
					E5-04	Udc Lower for ? sec	0~255	1sec	0sec		80
					E5-05	Udc Higher than ? V	NOTE 3	0.01V	NOTE 3		80
					E5-06	Udc Higher for ? sec	0~255	1sec	0sec		80
					E5-07	Not Charge for ? sec	0~255	1sec	0sec		80
					E5-08	Fan ON for ? sec	0~255	1sec	0sec		80
					E5-09	When bulk Protection	0~1	1	0	0:Disable 1:Enable	80
					E5-10	System Fault Occurs	0~1	1	0	0:Disable 1:Enable	80
					E5-11	Temp. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E5-12	Temp. Alarm for ?sec	0~255	1sec	0sec		80
					E5-13	Low Batt. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E5-14	Low Batt. for ? sec	0~255	1sec	0sec		80
					E5-15	Overload Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E5-16	OL Alarm for ? sec	0~255	1sec	0sec		80

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programm- ing	E	Aux-Relay	E5	Set Aux- Relay 3 ON	E5-17	Udc Ripple Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E5-18	UdcRipAlarm for ?sec	0~255	1sec	0sec		80
			E6	Set Aux- Relay 3 OFF	E6-01	Load Lower than ? A	NOTE 3	0.01A	NOTE 3		80
					E6-02	Load Lower for ? sec	0~255	1sec	0sec		80
					E6-03	Udc Lower than ? V	NOTE 3	0.01V	NOTE 3		80
					E6-04	Udc Lower for ? sec	0~255	1sec	0sec		80
					E6-05	Udc Higher than ? V	NOTE 3	0.01V	NOTE 3		80
					E6-06	Udc Higher for ? sec	0~255	1sec	0sec		80
					E6-07	Charging for ? sec	0~255	1sec	0sec		80
					E6-08	Fan OFF for ? sec	0~255	1sec	0sec		80
					E6-09	Charge Finished ?Min	0~1000	1min	0		80
					E6-10	RY3 not ON for ?mins	0~1000	1min	0		80
					E6-11	AC IN Loss for ?sec	0~255	1sec	0sec		80
					E6-12	No Temp. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E6-13	No Temp. Alarm ? sec	0~255	1sec	0sec		80
					E6-14	No Low Bat. Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E6-15	No Low Bat for ? sec	0~255	1sec	0sec		80
					E6-16	No OL Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E6-17	No OL Alarm for ? sec	0~255	1sec	0sec		80
					E6-18	No UdcRipple Alarm Sel	0~1	1	0	0:Alarm 1:Pre-alarm	80
					E6-19	No UdcRipple Alarm ?sec	0~255	1sec	0sec		80
			E7	Aux- Relay 1 Option	E7-01	Aux1 Usage Select	0~1	1	0	0:Do not use Aux 1: Use Aux	81
					E7-02	Aux1 Invert Select	0~1	1	0	0: Normal 1: Invert switch	81
					E7-03	Aux1 notSwitchOff T	0~1000	1 min	0		81

Menu	Group		Function		Constant	LCD Display	Range	Unit	Factory Setting	Remark	Page
Programm- ing	E	Aux-Relay	E8	Aux-Relay 2 Option	E8-01	Aux2 Usage Select	0~1	1	0	0:Do not use Aux 1: Use Aux	81
					E8-02	Aux2 Invert Select	0~1	1	0	0: Normal 1: Invert switch	81
					E8-03	Aux2 notSwitchOff T	0~1000	1 min	0		81
			E9	Aux-Relay 3 Option	E9-01	Aux3 Usage Select	0~1	1	0	0:Do not use Aux 1: Use Aux	81
					E9-02	Aux3 Invert Select	0~1	1	0	0: Normal 1: Invert switch	81
					E9-03	Aux3 notSwitchOff T	0~1000	1 min	0		81
	F	Solar Charger	F1	Solar Charger	F1-01	Solar Charger Enable	0~1	1	1	0: Disable 1: Enable NOTE 5	—
					F1-02	Reset Amp-Hours	0~1	1	0	0: No 1: Yes NOTE 5	—
					F1-03	Solar Monitor Sel	0~10	1	0	0: Sum of display 1~10: independent display NOTE 5	—
	O	Operator	O1	Monitor Select	O1-01	Power-ON Monitor Sel	0~26	1	4	NOTE 4	82
					O1-02	Key Idle Detect Time	10~600	1sec	180 sec		82
			O2	Key Selections	O2-01	Key Pressed Beep Sel	0~1	1	1	0:Disable 1:Enable	82
					O2-02	Elapsed Time Reset	0~60000	1hour	0		82
					O2-03	Elapsed Time Select	0~1	1	0	0:Power ON 1: Run Time	82
					O2-04	Stakcable Inverter Model	—	—	—		82
					O2-06	MODE Key Hold Time	2~10	1sec	5 sec		82
					O2-07	RUN/STOP KeyHoldTime	2~10	1sec	2 sec		83
					O2-08	Auto Run Select	0~1	1	1	0: Manual 1: Auto	83
					O2-09	Display IdleTime Set	0~60	1min	10 min		83

NOTE 2:

U1-10 = X X X

Aux-Relay1:

0=OFF

1=ON

Aux-Relay2:

0=OFF

1=ON

Aux-Relay3:

0=OFF

1=ON

NOTE 3:

Constants Model	B2-01			B2-02			B2-03			B2-04		
	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting
PM-1500SI-122	180~230	1V	180V	181~260	1V	187V	240~269	1V	265V	230~270	1V	270V
PM-3000SI-122	180~230	1V	180V	181~260	1V	187V	240~269	1V	265V	230~270	1V	270V
PM-1500SI-242	180~230	1V	180V	181~260	1V	187V	240~269	1V	265V	230~270	1V	270V
PM-3000SI-242	180~230	1V	180V	181~260	1V	187V	240~269	1V	265V	230~270	1V	270V
PM-1500SI-121	94~120	1V	94V	95~135	1V	101V	128~142	1V	138V	120~143	1V	143V
PM-3000SI-121	94~120	1V	94V	95~135	1V	101V	128~142	1V	138V	120~143	1V	143V
PM-1500SI-241	94~120	1V	94V	95~135	1V	101V	128~142	1V	138V	120~143	1V	143V
PM-3000SI-241	94~120	1V	94V	95~135	1V	101V	128~142	1V	138V	120~143	1V	143V

Constant Model	B2-05			C1-01			C1-02			C1-03		
	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting
1500SI-122	1.0~16.0	0.1A	16.0A	210~245	1V	230V	9.3~13.0	0.01V	9.3V	10.9~17.0	0.01V	10.9V
3000SI-122	1.0~16.0	0.1A	160.A	210~245	1V	230V	9.3~13.0	0.01V	9.3V	10.9~17.0	0.01V	10.9V
1500SI-242	1.0~16.0	0.1A	16.0A	210~245	1V	230V	18.6~26.0	0.01V	18.6V	21.8~34.0	0.01V	21.8V
3000SI-242	1.0~16.0	0.1A	16.0A	210~245	1V	230V	18.6~23.0	0.01V	18.6V	21.8~34.0	0.01V	21.8V
1500SI-121	2.0~30.0	0.1A	30.0A	94~128	1V	120V	9.3~13.0	0.01V	9.3V	10.9~17.0	0.01V	10.9V
3000SI-121	2.0~30.0	0.1A	30.0A	94~128	1V	120V	9.3~13.0	0.01V	9.3V	10.9~17.0	0.01V	10.9V
1500SI-241	2.0~30.0	0.1A	30.0A	94~128	1V	120V	18.6~26.0	0.01V	18.6V	21.8~34.0	0.01V	21.8V

3000SI-241	2.0~30.0	0.1A	30.0A	94~128	1V	120V	18.6~23.0	0.01V	18.6V	21.8~34.0	0.01V	21.8V
-------------------	----------	------	-------	--------	----	------	-----------	-------	-------	-----------	-------	-------

Constant Model	D1-03			D1-07			D1-08			E1-01,E3-01,E5-01		
	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting
PM-1500SI-122	12.0~16.0	0.01V	14.40V	12.0~16.0	0.01V	13.80V	0~70	1A	35A	0~29.3	0.01A	6.65A
PM-3000SI-122	12.0~16.0	0.01V	14.40V	12.0~16.0	0.01V	13.80V	0~140	1A	70A	0~42.6	0.01A	13.30A
PM-1500SI-242	24.0~32.0	0.01V	28.80V	24.0~32.0	0.01V	27.60V	0~35	1A	17A	0~29.3	0.01A	6.65A
PM-3000SI-242	24.0~32.0	0.01V	28.80V	24.0~32.0	0.01V	27.60V	0~70	1A	35A	0~42.6	0.01A	13.30A
PM-1500SI-121	12.0~16.0	0.01V	14.40V	12.0~16.0	0.01V	13.80V	0~70	1A	35A	0~44.7	0.01A	12.75A
PM-3000SI-121	12.0~16.0	0.01V	14.40V	12.0~16.0	0.01V	13.80V	0~140	1A	70A	0~83.0	0.01A	25.5A
PM-1500SI-241	24.0~32.0	0.01V	28.80V	24.0~32.0	0.01V	27.60V	0~35	1A	17A	0~44.7	0.01A	12.75A
PM-3000SI-241	24.0~32.0	0.01V	28.80V	24.0~32.0	0.01V	27.60V	0~70	1A	35A	0~83.0	0.01A	25.5A

Constant Model	E1-03,E3-03,E5-03			E1-05,E3-05,E5-05			E2-01,E4-01,E6-01			E2-03,E4-03,E6-03		
	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting	Range	Unit	Factory Setting
PM-1500SI-122	0~17.5	0.01V	11.75V	0~17.5	0.01V	16.0V	0~29.3	0.01A	1.66A	0~17.5	0.01V	11.75V
PM-3000SI-122	0~17.5	0.01V	11.75V	0~17.5	0.01V	16.0V	0~42.6	0.01A	3.32A	0~17.5	0.01V	11.75V
PM-1500SI-242	0~35.0	0.01V	23.5V	0~35.0	0.01V	32.0V	0~29.3	0.01A	1.66A	0~35.0	0.01V	23.5V
PM-3000SI-242	0~35.0	0.01V	23.5V	0~35.0	0.01V	32.0V	0~42.6	0.01A	3.32A	0~35.0	0.01V	23.5V
PM-1500SI-121	0~17.5	0.01V	11.75V	0~17.5	0.01V	16.0V	0~44.75	0.01A	3.18A	0~17.5	0.01V	11.75V
PM-3000SI-121	0~17.5	0.01V	11.75V	0~17.5	0.01V	16.0V	0~83.0	0.01A	6.37A	0~17.5	0.01V	11.75V
PM-1500SI-241	0~35.0	0.01V	23.5V	0~35.0	0.01V	32.0V	0~44.75	0.01A	3.18A	0~35.0	0.01V	23.5V
PM-3000SI-241	0~35.0	0.01V	23.5V	0~35.0	0.01V	32.0V	0~83.0	0.01A	6.37A	0~35.0	0.01V	23.5V

Constant Model	E2-05,E4-05,E6-05		
	Range	Unit	Factory Setting
PM-1500SI-122	0~17.5	0.01V	16.0V
PM-3000SI-122	0~17.5	0.01V	16.0V
PM-1500SI-242	0~35.0	0.01V	32.0V
PM-3000SI-242	0~35.0	0.01V	32.0V
PM-1500SI-121	0~17.5	0.01V	16.0V
PM-3000SI-121	0~17.5	0.01V	16.0V
PM-1500SI-241	0~35.0	0.01V	32.0V
PM-3000SI-241	0~35.0	0.01V	32.0V

NOTE 4:

Parameter	Setting	LCD Display
O1-01=	0	AC IN Voltage
	1	AC IN Current
	2	AC OUT Voltage
	3	AC OUT Current
	4	Battery Voltage
	5	Battery Ripple Volt
	6	Battery Current
	7	Control Mode
	8	Operation Status
	9	Aux-Relay Status
	10	Elapsed Time
	11	Bat.Temp.Sensor
	12	CPU ID 1
	13	CPU ID 2
	14	Solar Charger Status
	15	Solar Supply Current
	16	Solar Supply Power
	17	Solar Amp-Hours
	18	Solar Total Amp-Hours
	19	DC Generator Status

NOTE 5:

The constants marked with NOTE 5 are only visible when extension port (Port C) is connected. After power on, the Stakcable Inverter will start to scan each built-in module and extension module. The constants marked with NOTE 5 will be visible only when the extension port (Port C) is connected with extension module.

A1-04=Password 1

Lock the constants setting (A1-01=1)

1. Finish setting all the programmable parameters to desired values.
2. Change A1-01=0 (Operation only), factory setting is A1-01=1 (Constants set).
3. Go to A1-04 and press RUN/STOP key and UP key at the same time till A1-05 parameter occurs.
4. Enter the desired password (max. 4 digits)

5. Press UP key to leave A1-05

Above procedure completes locking the constants setting and no more programming selection would appear. A1-01 would only display 0 (Operation only) and would not display 1 (Constants set).

Unlock the constants setting

1. Enter the password in A1-04 to be exactly the same as the one earlier set in A1-05
2. When the password in A1-04 matches the one earlier set in A1-05, the unlocking is completed. A1-01=1 (Constants set) would appear again for programming.

Chapter 6 Programming Constants

A Group (Initialize):

A1 Group (Initialize)

A1-01: Access level

- Use constant A1-01 to select the user constant access level.
This level determines which user constants can be changed and displayed.

Setting	Function
A1-01=0	This setting allows the “operation” and “initialize” to be changed or displayed. Use this setting to prevent user constant settings from being changed.
A1-01=1 (Initial setting)	This setting allows all user constants to be changed or displayed.

A1-02: Select Language

- Use constant A1-02 to select the language displayed by the Stackable Inverter. A value of 0 set English and values of others set other language.
- This user constant is not returned to factory setting when constants are initialized. It must be manually reset to factory setting.

Setting	Function
A1-02=0 (Initial setting)	English language
A1-02=1	Reserved, under development
A1-02=2	Reserved, under development
A1-02=3	Reserved, under development
A1-02=4	Reserved, under development
A1-02=5	Reserved, under development
A1-02=6	Reserved, under development

A1-03: Init Parameters

- Use constant A1-03 to initialize the user constants.
- When initialized, the user constants will return to their factory preset values. You should normally record the setting of any constants that are changed from factory presets.

Setting	Function
A1-03=0 (Initial setting)	Returns to initialize Display without initializing any user constants.
A1-03=1	Initializes the user constants to factory settings.

A1-04: Init Password 1

- This constant is reserved for the factory to test and set the functions.
- Users are not allowed to set this constant.

Lock the constants setting (A1-01=1)

1. Finish setting all the programmable parameters to desired values.
2. Change A1-01=0 (Operation only), factory setting is A1-01=1 (Constants set).
3. Go to A1-04 and press RUN/STOP key and UP key at the same time till A1-05 parameter occurs.
4. Enter the desired password (max. 4 digits)
5. Press UP key to leave A1-05

Above procedure completes locking the constants setting and no more programming selection would appear. A1-01 would only display 0 (Operation only) and would not display 1 (Constants set).

Unlock the constants setting

1. Enter the password in A1-04 to be exactly the same as the one earlier set in A1-05
2. When the password in A1-04 matches the one earlier set in A1-05, the unlocking is completed. A1-01=1 (Constants set) would appear again for programming.

B Group (General):

B1 Group (Output Frequency)

B1-01: Output frequency

- B1-01 is used to set the output frequency at INVERTER AC output

Setting	Function
B1-01=0 (Initial setting)	50Hz at INVERTER AC output
B1-01=1	60Hz at INVERTER AC output

- B2-08: AC IN Frequency Range

Setting	Function
B2-08=0	When B1-01=0: Acceptable AC input frequency is 50Hz \pm 5Hz (45~55Hz)
	When B1-01=1: Acceptable AC input frequency is 60Hz \pm 5Hz (55~65Hz)
B2-08=1 (Initial setting)	Accept wide AC input frequency range between 45~65Hz

B2 Group (Auto Transfer Switch)

B2-01: AC IN Low Disconnect

- Use constant B2-01 to determine the AC IN voltage below which level the ATS (Auto Transfer Switch) will switch off.
- This voltage level will always lie below the AC IN Low Connect (B2-02) level. In fact, changing this level will also change the AC IN Low Connect (B2-02) level.

B2-02: AC IN Low Connect

- This setting forms a pair with AC IN Low Disconnect (B2-01). With this setting, one determines the AC IN low voltage at which level the ATS will switch on. This should lie above AC IN Low Disconnect (B2-01) level to prevent continuous switching off the ATS when the voltage is fluctuating around the level.
 - In fact, the parameter which is changed is the difference between AC IN Low Disconnect (B2-01) and AC IN Low Connect (B2-02).
 - The result of this is that when changing B2-01 level, this level (B2-02) also changes.
- ※ Note: B2-02 can be ignored for a short time when AC IN Waveform Check (B2-06) is

- disabled (B2-06=0)
- When the AC IN voltage drops due to the increasing charge current, the AC CHARGER will take care that the voltage does not drop below this level.
- $B2-02 = B2-01 + \text{offset voltage}$
For example: PM-1500SI-122, when $B2-01 = 180V$, $B2-02 = 187V$, offset voltage = $7V$ ($187 - 180$), $B2-02$ will automatically go to $197V(190 + 7)$ after $B2-01$ is changed to $190V$.

B2-03: AC IN High Connect

- This setting forms a pair with AC IN High Disconnect (B2-04). With this setting, one determines the AC IN high voltage at which level the ATS will switch on. This should lie below the AC IN High Disconnect (B2-04) level to prevent continuous switching of the ATS when the voltage is fluctuating around that level.
- In fact, the parameter which is changed is the difference between AC IN High Disconnect (B2-04) and AC IN High Connect (B2-03).
- The result of this is that when changing B2-04 level, this level (B2-03) also changes.
- $B2-03 = B2-04 - \text{offset voltage}$
For example: PM-1500SI-122, when $B2-03 = 265V$, $B2-04 = 270V$, offset voltage = $5V$ ($270 - 265$), $B2-03$ will automatically go to $255V(270 - 5)$ after $B2-04$ is changed to $260V$.

B2-04: AC IN High Disconnect

- Use constant B2-04 to determine the AC IN voltage above which level the ATS will switch off.
- This voltage level will always lie above the AC IN High Connect (B2-03) level. In fact, changing this level will also change the AC IN High Connect (B2-03) level.

B2-05: AC IN Current Limit

- Use constant B2-05 to set the set the specific maximum AC input current. This value is very important for both battery charger and inverter output power assist.
 - When using constant B2-05, the values determine the actual AC current limit.
- ※Note: With Power Support enabled, there is a minimum value for the AC input current limit.
Please see the note at Power Support (page 71).

B2-06: AC IN Waveform Check

- Use constant B2-06 to enable/disable the fast detection of input voltage wave shape.

Setting	Function
B2-06=0 (Ignore)	<ul style="list-style-type: none"> By disabling AC IN waveform check, <u>AC IN Low Disconnect</u> (B2-01) is ignored. When the load current is higher 1.5 times than <u>AC In Current Limit</u> (B2-05), this is used to prevent unnecessary switching to INVERTER due to voltage drop when a high load is connected.
B2-06=1 (Initial setting) (Active)	<ul style="list-style-type: none"> This detection checks the wave shape, if it is not sinusoidal within certain limits, the AC input voltage is rejected. However, certain generator or very weak mains supply have an ill shaped sinusoidal output especially when the load suddenly changes. The fast detection will detect a failure in such a case. This will result in a slightly longer transfer time.

B2-07: Ground Relay

- Used to enable/disable the internal ground relay functionality. The ground relay is useful when an earth-leakage circuit-breaker is part of the installation.
- When ATS (Auto Transfer Switch) is open (INVERTER mode), the Neutral of the inverter is connected to “G” terminal.
- When ATS closes (AC IN is transferred to AC OUT), the Neutral is first disconnected from “G” terminal.

Setting	Function
B2-07=0	The internal ground relay is open with “G” terminal.
B2-07=1 (Initial setting)	The internal ground relay is closed with “G” terminal.

B2-08: AC IN Frequency Range

Refer to page 64 (B1-01)

B2-09: AC IN Dynamic Current Limit

- This setting is an expansion of the AC IN Current Limit (B2-05) mechanism.

Setting	Function
B2-09=0 (Initial setting)	<ul style="list-style-type: none"> The AC current limit is specified by the <u>AC IN Current Limit</u> (B2-05) setting

B2-09=1	<ul style="list-style-type: none"> ● The effective AC input current limit depends on the load history. When the load is lower than the <u>AC IN Current Limit</u> (B2-05), the effective AC input current limit is also lower but slightly above the load. ● When the load increase, the effective current limit also increases with a delay. The thought behind this is that when a generator is running at a low load, it can't switch to full load immediately and it needs some time to increase the power.
---------	---

※ An example:

- We have a 2KVA generator.
We adjust the AC IN Current Limit (B2-05) setting to 8A and we enable Power Assist (C1-05=1). We have no load connected and the batteries are fully charged. Therefore, no current from generator is drawn.
- At this moment, we connect a load of 7A to the Stackable Inverter with this setting (B2-09) disabled, the Stackable Inverter would not react because the load is below the AC IN Current Limit (B2-05) setting. The result is that the full load is connected to generator which will drop in voltage because it can't deliver that current instantly which could result in switching to INVERTER.
- If however we had this setting (Dynamic Current Limit) enabled, the effective AC input current limit would be far lower than 8A because the load was zero. So connecting a load of 7A will result in Stackable Inverter starting to power assist and no voltage drop is being examined on the AC OUT. The generator starts to supply the load and the effective AC input current limit will increase to 8A slowly. At the moment, the Stackable Inverter will stop Power Assist and the full load is on the generator.
- This is powerful option in combination with Power Assist but even without Power Assist, it can prevent unnecessary switching to INVERTER because the charge current will reduce when AC input current becomes higher than the effective AC input current limit.

B2-10: MODE4: Bat Lo?V ATS ON
B2-11: MODE4: Bat Lo?S ATS ON
B2-12: MODE4: Bat Hi?V ATSOFF
B2-13: MODE4: Bat Hi?S ATSOFF
B2-14: MODE3: Bat Lo?V ATS ON
B2-15: MODE3: Bat Lo?S ATS ON
B2-16: MODE3: Bat Hi?V ATSOFF
B2-17: MODE3: Bat Lo?S ATSOFF

- B2-10~B2-13 are used to set the condition of ATS to be ON/OFF in MODE4
- B2-14~B2-17 are used to set the condition of ATS to be ON/OFF in MODE3
- When Stackable Inverter is in either MODE4 or MODE3, INVERTER mode takes priority to supply voltage to AC OUT for load consumption. When AC IN power is ready, INVERTER is active and battery is about to be exhausted, ATS will be switched on to ensure AC OUT to continuously supply the load. At the moment, AC OUT will be supplied by AC IN power. At the same time, the battery can be charged by other renewable energy such as solar charger, wind charger or DC generator charger (MODE3) which is normally the solar house application in no need of AC CHARGER. The battery can be charged by AC IN (AC CHARGER) or other renewable energy such as solar charger, wind charger or DC generator charger (MODE4) which is normally the application requesting both AC charging and DC charging.
- When charging battery slowly reaches to certain level, this means battery will be fully charged soon and the ATS will be switched off for INVERTER to take over the ongoing supply to AC OUT for load.
- B2-10 and B2-11 are used to set ATS to be “ON” when the battery voltage is lower than B2-10 voltage value and longer than the second time set in B2-11 in MODE4.
(INVERTER OFF+ATS ON+AC CHARGER ON)
- B2-12 and B2-13 are used to set ATS to be “OFF” when the battery voltage is higher than B2-12 voltage value and longer than the second time set in B2-13 in MODE4.
(INVERTER ON+ATS OFF+AC CHARGER OFF)
- B2-14 and B2-15 are used to set ATS to be “ON” when the battery voltage is lower than B2-14 voltage value and longer than the second time set in B2-15 in MODE3.
(ATS ON+INVERTER OFF+AC CHARGER ON)
- B2-16 and B2-17 are used to set ATS to be “OFF” when the battery voltage is higher than B2-16 voltage value and longer than the second time set in B2-17 in MODE3.
(INVERTER ON+ATS OFF+ AC CHARGER OFF)

B2-18: MODE1: ACIN Current Lmt

- Use constant B2-18 to set the set the specific maximum AC input current in MODE 1. This value is very important for both battery charger and inverter output power assist.
- When using constant B2-18, the values determine the actual AC current limit.

B2-19: MODE2: ACIN Current Lmt

- Use constant B2-19 to set the set the specific maximum AC input current in MODE 2. This value is very important for both battery charger and inverter output power assist.
- When using constant B2-19, the values determine the actual AC current limit.

B2-20: MODE3: ACIN Current Lmt

- Use constant B2-20 to set the set the specific maximum AC input current in MODE 3. This value is very important for both battery charger and inverter output power assist.
- When using constant B2-20, the values determine the actual AC current limit.

B2-21: MODE4: ACIN Current Lmt

- Use constant B2-21 to set the set the specific maximum AC input current in MODE 4. This value is very important for both battery charger and inverter output power assist.
- When using constant B2-21, the values determine the actual AC current limit.

B3 Group (Parallel System)

B3-01: Number of Slaves

- A parallel system is built with 1 master and up to 4 slaves with this setting, one can specify the number of slaves in system. This setting has only to be done in the master. It is not required to specify the number of slaves. The system will work just fine without this setting being specified.
- This setting is added for convenience of the end-user when the AC IN power is larger than the total of B2-05* the number of the Stackable Inverter (Master + Slaves) when B3-01=0. The only effect of this setting is on the scaling of AC IN Current Limit (B2-05). If B3-01=0, one must divide the available AC current by the number of Stackable Inverter (Master + Slaves) and set the limit accordingly. So an example of setting the B2-05=10A in a parallel system with 3 Stackable Inverter would result in a limit of $3 \times 10A = 30A$
- If however in this system the number of slaves is set 2 (B3-01=2), then the division is done internally and setting the AC IN Current Limit to 10A (B2-05=10) will result in 10A for the whole system and shared by the Master and Slaves. This system is often applied when the AC IN power is limited such as the generator of limited small capacity.

B4 Group (2-3 Phase)

B4-01: 2-3 Phase Connection

- All the Stackable Inverter in a multi-phase system must have 2-3 phase enabled. Use this setting to perform this.
- If more Stackable Inverter per phase are connected in parallel, then only the masters of parallel system must have 2-3 phase enabled.

Setting	Function
B4-01=0 (Initial setting)	2-3 Phase connection disabled.
B4-01=1	2-3 Phase connection enabled.

B4-02: 2-3 Phase Master

- In a multi-phase system, there is always one (and only one) master. The Stackable Inverter for other phases are called followers.
- Use this setting to designate one of the Stackable Inverters is master. If this parameter is set (B4-02=0), the Stackable Inverter is a follower.

Setting	Function
B4-02=0 (Initial setting)	2-3 Phase connection system is called Follower
B4-02=1	2-3 Phase connection system is called Master

B4-03: 2-3 Phase Type

- Use constant B4-03 to determine the kind of multi-phase required.

Setting	Function
B4-03=0 (Initial setting)	3 Phase type: Three Stackable Inverters are required. Output is 3-phase with 120° phase shift.
B4-03=1	Split Phase 180° Type: Two Stackable Inverters are required. Output is 2-phase with phase 180° shift
B4-03=2	Two Leg 3 Phase 120° Type: Two Stackable Inverters are required. Output is 2-phase of a normal 3-phase system so two phases with 120° phase shift.

C Group (INVERTER):
C1 Group (INVERTER)

C1-01: INVERTER Output Voltage

- Use constant C1-01 to change the RMS output voltage of the INVERTER.

C1-02: Bat Low ? V Shut-down

- With this setting, one can determine the battery voltage at which level the INVERTER will switch off. This can be useful to prevent drawing too much current from an exhausted battery.
- This voltage level will always lie below the Bat Low ? V Restart (C1-03) level. In fact, changing this level will also change the Bat Low ? V Restart (C1-03) level.
- $C1-03 = C1-02 + \text{offset voltage}$
For example: PM-1500SI-122, when $C1-02 = 9.3V$, $C1-03 = 10.9V$, offset voltage = $1.6V$ ($10.9 - 9.3$), $C1-03$ will automatically go to $11.6V$ ($10.0 + 1.6$) after $C1-02$ is changed to $10.0V$.

C1-03: Battery Low ? V Restart

- This setting forms a pair with Bat Low ? V Shut-down (C1-02). With this setting, one determines the battery voltage at which level the INVERTER will switch on.
- In fact, the parameter which is changed is the difference between Bat Low ? V Shut-down (C1-02) and Bat Low ? V Restart (C1-03). The result of this is that when changing the Bat Low ? V Shut-down (C1-02) level, this level also changes.

C1-05: Power Assist Select

- Using this constant C1-05, the Power Assist feature can be enabled or disabled. Use Power Assist to prevent an external circuit breaker to trip when the load on the Stackable Inverter is too high.
- If the load exceeds the AC IN Current Limit (B2-05), the Stackable Inverter will start inverting and will provide the extra current needed.
- ※ Note: When Power Assist is enabled. $C1-05 = 1$ (Initial setting), there is a minimum AC input current limit of approximate 2-3 Amps. Setting a lower limit (B2-05) than this minimum value will result in the minimum limit. (Note: In a parallel system, this limits per Stackable Inverter!)

Setting	Function
C1-05=0	Power Assist Function is disabled.
C1-05=1 (Initial setting)	Power Assist Function is enabled.

C1-06: Power Assist Level

- This setting is a special setting for power assist mode when the Stackable Inverter is charging and due to a sudden load, the AC IN current exceeds the AC IN Current Limit (B2-05), the Stackable Inverter will switch to power assist mode (when C1-05=1)
- At that moment, the current need is unknown. The Stackable Inverter makes an assumption of the magnitude of this current. This assumption is equal to AC IN Current Limit (B2-05) multiplied by this Power Assist Level (C1-06). The default factor is two.
- This will prevent the circuit breaker from tripping because current provided by the INVERTER minus the current drawn by the load is always lower than the rating of the circuit breaker. This happens, of course, when the AC IN Current Limit (B2-05) is correctly adjusted to the circuit breaker.
- If for instance in a generator application, the circuit breaker has a higher value than the AC IN Current Limit (B2-05) (Normal load of generator is lower than maximum peak load) and one knows that the load which is switched on always draws a certain current, one can consider to increase this factor (C1-06) to achieve better results with sudden load changes.


D Group (AC CHARGER):

D1 Group (Charger)

D1-02: Charge Curve

Setting	Function
D1-02=1	Fixed
D1-02=2	Adaptive
D1-02=3 (Initial setting)	Adaptive + Battery safe

- The Fixed (D1-02=1) charge curve will have a fixed Absorption Time (D1-06).
- The Adaptive (D1-02=2) and Adaptive + Battery safe (D1-02=3) curve derive the Absorption time from the Bulk time. The maximum Absorption time of these charge curves is determined by Absorption Time (D1-06) setting.
- The Adaptive + Battery safe (D1-02=3) curve has a special regulation in the absorption phase. The absorption phase will start when the battery voltage reaches 14.4V(for 12V batteries) regardless of the specified Absorption Voltage (D1-03). During the absorption phase, the voltage will increase with a fixed ramp until the voltage reaches the absorption voltage or the calculated absorption time is over in the latter case, the absorption phase will end before the absorption voltage is reached.



D1-03: Absorption Voltage

- Use this setting to specify the absorption voltage.

D1-04: Repeated Absorption Time

- Use this setting to specify the duration of the repeated absorption “pulses”.

D1-05: Repeated Absorption Interval

- Use this setting to specify the interval between repeated absorptions.

D1-06: Maximum Absorption Time

- If the Charge Curve is fixed (D1-02=1), then this setting is used to determine the absorption time.
- In all other cases, this setting determines the maximum absorption time.

D1-07: Float Voltage

- Use this setting to specify the float voltage.

D1-08: Charge Current

- Use this setting to specify the current with which the battery is charged in the bulk phase.
- ✘ Note: The actual charge current depends on other conditions also. Therefore, under certain circumstances, it is possible that the actual charge current is lower than this setting. This can, among others, be due to:
 - A low AC IN Current Limit (B2-05) in combination with a high load.
 - A high environmental temperature
 - A too high ripple voltage due to improper cabling.

D1-09: Stop After 10Hr Bulk

- This is a safety setting. When the bulk phase lasts more than 10 hours, this can be indication that a battery cell is damaged.
- The absorption voltage (or the 14.4V for battery when Battery Safe (D1-02=3) mode is used) will never be reached in that case and the other cells will be over-charged resulting in the

production of an explosive gas.

- Therefore, the charger is disabled if the bulk phase lasts more than 10 hours.
- This setting can be disabled because it does not always indicate a problem when the bulk phase lasts very long. The charge current can be very low due to limited AC input current and/or AC loads. Also, DC loads can “steal away” part of the charge current. In that case, the bulk phase will need more time to complete and this setting must be disabled.

※ Note: When this setting is disabled, there is no safety check against over-charging.

Setting	Function
D1-09=0	<u>Stop After 10Hr Bulk</u> setting is disabled
D1-09=1 (Initial setting)	<u>Stop After 10Hr Bulk</u> setting is enabled

D1-10: Equalize Mode Select (Storage Mode Select)

- This setting is used for enabling/disabling the Equalize Mode.
- In this mode, the voltage setpoint is 13.2V (for 12V battery). If Equalize mode is disabled, then the normal float voltage will be used.

Setting	Function
D1-10=0	Equalize mode is disabled
D1-10=1 (Initial setting)	Equalize mode is enabled

E Group (Auxiliary Relay):

E1 Group (Setting Aux-Relay 1 ON Condition)

E1-01: LOAD Higher than ? Amps

E1-02: LOAD Higher for ? sec

- Use these settings to switch the Aux-Relay 1 ON. When the actual AC OUT load is above a certain value (E1-01) for a certain time (E1-02).
 - The corresponding Aux-Relay 1 OFF condition is
E2-01: Load Lower than ? Amps and
E2-02: Load Lower for ? sec.
- ※ Note: If setting E1-02=0 sec (Initial setting). Then the E1-01 is ignored.
- ※ Note: If setting E2-02=0 sec (Initial setting). Then the E2-01 is ignored.

E1-03: Udc Lower than ? Voltage

E1-04: Udc Lower for ? sec

- Use these settings to switch the Aux-Relay 1 ON. When battery voltage becomes lower than a certain limit (E1-03) for a certain time (E1-04).
- ※ Note: If E1-04=0 sec (Initial setting), then E1-03 is ignored.

E1-05: Udc Higher than ? Voltage

E1-06: Udc Higher for ? sec

- Use these settings to switch the Aux-Relay 1 ON when battery voltage becomes higher than a certain limit (E1-05) for a certain time (E1-06).
- ※ Note: If E1-06=0 sec (Initial setting), then E1-05 is ignored.

E1-07: Not Charge for ? sec

- Use this setting to switch on the Aux-Relay 1 when the AC CHARGER is not charging for a certain time (E1-07).
- Normally used for generating an alarm situation.

E1-08: Fan ON for ? sec

- This will switch the Aux-Relay 1 ON when the internal fan switches on. This can be used together with the E2-08: Fan OFF for ? sec setting to drive an external fan.

E1-09: When bulk protection is activated.

- This will set the Aux-Relay1 ON when the “bulk protection” (D1-09=1) is activated. This condition will remain valid as long as the AC CHARGER is disabled due to that safety mechanism. One can use this setting to generate an alarm.

E1-10: System Fault Occurs

- This will switch on the Aux-Relay 1 when the Stackable Inverter switches off due to an internal alarm situation.

E1-11: Temp. Alarm Select (When E1-12=0, ignore this setting)**E1-12: Temp. Alarm for ? sec**

- If you want to switch on the Aux-Relay 1 when there is a over temperature alarm, this setting (E1-11) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 settings, a delay value (E1-12) must be specified also. This can be done with Delay value for set Aux-Relay 1 ON when over temperature alarm (E1-12) setting.

E1-13: Low Batt. Alarm Select (When E1-14=0, ignore this setting)**E1-14: Low Batt. Alarm for ? sec**

- If you want to switch on the Aux-Relay 1 when there is a low battery alarm, this setting (E1-13) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 settings, a delay value (E1-14) must be specified also. This can be done with Delay value for set Aux-relay 1 ON when low battery alarm (E1-14) setting.

E1-15: OverLoad Alarm Select (When E1-16=0, ignore this setting)**E1-16: OverLoad Alarm for ? sec**

- If you want to switch on the Aux-Relay 1 when there is a overLoad alarm, this setting (E1-15) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 setting, a delay value (E1-16) must be specified also. This can be done with Delay value for set Aux-Relay 1 ON when overload alarm (E1-16) setting.

E1-17: Udc Ripple Alarm Select (When E1-18=0, ignore this setting)**E1-18: OverLoad Alarm for ? sec**

- If you want to switch on the Aux-Relay 1 when there is a battery voltage ripple alarm. This setting (E1-17) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 2, setting a delay value (E1-18) must be specified also. This can be done with Delay value for set Aux-Relay 1 ON when battery voltage ripple alarm (E1-18) setting.

E2 Group (Setting Aux-Relay 1 OFF Condition)

E2-01: Load Lower than ? Amps

E2-02: Load Lower for ? sec

- Use these settings to switch Aux-Relay 1 OFF. When the actual AC OUT Load is below a certain value (E2-01) for a certain time (E2-02).
 - The corresponding Aux-Relay ON condition is
E1-01: Load Higher than ? Amps and
E1-02: Load Higher for ? sec.
- ※ Note: If setting E2-02 (E1-02)=0 sec (Initial setting), then the E2-01 (E1-01) is ignored.

E2-03: Udc Lower than ? Voltage

E2-04: Udc Lower for ? sec

- Use these settings to switch off the Aux-Relay 1 when battery voltage becomes lower than a certain limit (E2-03) for a certain time (E2-04)
- ※ Note: If E2-04=0 sec (Initial Setting), then E2-03 is ignored.

E2-05: Udc Higher than ? Voltage

E2-06: Udc Higher for ? sec

- Use these settings to switch off the Aux-Relay 1 when battery voltage becomes higher than a certain limit (E2-05) for a certain time (E2-06)
- ※ Note: If E2-06=0 sec (Initial setting), then E2-05 is ignored.

E2-07: Charging for ? sec

- This setting switches the Aux-Relay 1 OFF when the AC CHARGER started for a certain time (E2-07). This can be useful when the Aux-Relay 1 is for instance used a low battery alarm.
- Use the Set Udc Lower than ? Voltage (E1-03) setting to start the alarm and use this setting (E2-07) to stop it.

※ Note: As long as the battery voltage is lower than the specified limit (E1-03), the alarm will be active.

E2-08: Fan OFF for ? sec

- This will switch the Aux-Relay 1 OFF when the internal fan switches off. This can be used together with the E1-08: Fan ON for ? sec setting to drive an external fan.

E2-09: Charge finished for ? Min (When E2-09=0, ignore this setting)

- This condition becomes active when the charge bulk phase is finished for a certain time (E2-09).
- For the charge curve, take a look at for instance the Charge Current (D1-08) setting.
- This is useful when the Aux-Relay 1 is used to start a generator. Once started, one might want to keep the generator on until the batteries are more or less charged.

E2-10: Aux-Relay 1 not ON for ? minutes (When E2-10=0, ignore this setting)

- If one does not need special off condition, one can use this setting and the Aux-Relay 1 will switch off automatically when there has been no ON condition for a certain time (E2-10).

E2-11: AC IN loss for ? sec (When E2-11=0, ignore this setting)

- This setting will switch off Aux-Relay1 if the RMS value of AC IN voltage is too low for a certain time (E2-11).
- This AC level is determined by the AC IN Low Disconnect (B2-01) setting.
- Use this setting (E2-11) to disable re-starting of a generator which is switched off by hand when the Aux-Relay 1 is used to generate a start signal for that generator.

E2-12: No Temp. Alarm Select (When E2-13=0, ignore this setting)

E2-13: No Temp. Alarm for ? sec

- If you want to switch off the Aux-Relay 1 when there is no over temperature alarm, this setting (E2-12) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 setting, a delay value must be specified also. This can be done with the Delay value for set Aux-Relay 1 OFF when No Overtemperature Alarm (E2-13) setting.

E2-14: No Low Batt. Alarm Select (When E2-15=0, ignore this setting)

E2-15: No Low Batt Alarm for ? sec

- If you want to switch off the Aux-Relay 1 when there is no low battery alarm, this setting (E2-14) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 setting, a delay must be specified also. This can be done with the Delay value for set Aux-Relay 1 OFF when No Low Battery Alarm (E2-15) setting.

E2-16: No OverLoad Alarm Select (When E2-17=0, ignore this setting)

E2-17: No OverLoad Alarm for ? sec

- If you want to switch off the Aux-Relay 1 when there is no OverLoad alarm, this setting (E2-16) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 setting, a delay must be specified also. This can be done with the Delay value for set Aux-Relay 1 OFF when No OverLoad Alarm (E2-17) setting.

E2-18: No Udc Ripple Alarm Select (When E2-19=0, ignore this setting)

E2-19: No Udc Ripple Alarm for ? sec

- If you want to switch off the Aux-Relay 1 when there is no battery voltage ripple alarm, this setting (E2-18) can be used to choose between pre-alarm or normal alarm.
- As with other Aux-Relay 1 setting, a delay must be specified also. This can be done with the Delay value for set Aux-Relay 1 OFF when No Battery voltage Ripple Alarm (E2-19) setting.

E3 Group (Setting Aux-Relay 2 ON Condition)

E4 Group (Setting Aux-Relay 2 OFF Condition)

E5 Group (Setting Aux-Relay 3 ON Condition)

E6 Group (Setting Aux-Relay 3 OFF Condition)

※ Note: The functions and the settings of E3, E4, E5 and E6 Groups are exactly the same as those of E1 and E2 Group so please refer to above E1 and E2 Group description and setting for E3, E4, E5 and E6 Groups.

E7 Group (Aux-Relay 1 Option)

E7-01: Aux-Relay 1 Usage Select

Setting	Function
E7-01=0 (Initial setting)	Auxiliary Relay 1 is not allowed to be active (Idle).
E7-01=1	Auxiliary Relay 1 is allowed to be active.

E7-02: Aux-Relay 1 Invert Select

Setting	Function
E7-02=0 (Initial setting)	Auxiliary Relay 1 is normal.
E7-02=1	Auxiliary Relay 1 is Invert switch and that is ON becomes off and OFF becomes ON.

- This is used to invert the Aux-Relay 1 So ON becomes OFF and OFF becomes ON. In the program, the labels are adapted to reflect this inversion.

E7-03: Aux1 not Switch Off Time (Aux-Relay 1 do not switch off with certain period)

- Use constant E7-03 to determine the minimum ON time.
 - The Aux-Relay 1 will not be switched off within the time specified here measured from the moment that all on condition are inactive.
- ※ Note: OFF conditions with a delay of 0 minute, ignore this setting.

E8 Group (Aux-Relay 2 Option)

E9 Group (Aux-Relay 3 Option)

- ※ The functions and the settings of E8 and E9 Groups are exactly the same as those of E7 Group so please refer to above E7 Group description and setting for E8 and E9 Groups.

O Group (Operator):

O1 Group (Monitor Select)

O1-01: Power ON LCD Monitor Select

- After power of the Stackable Inverter is on, the monitor selections will be showed on LCD Display, U1-05 Battery Voltage is the initial display shown.
- All the constants in U1 Group can be programmed (U1-01~U-26).

O1-02: Key Idle Detect Time

- Use constant O1-02 to set the idle time when the keyboard is not operated and once any key is pressed, the display will return to the LCD monitor selection value set in constant O1-01.
- Initial Setting=180 sec, setting range: 10~600 sec.

O2 Group (Key Selections)

O2-01: Key Pressed Beep Select

Setting	Function
O2-01=0	When keys are pressed, beep sound will not be heard.
O2-01=1 (Initial setting)	When keys are pressed, beep sound will be heard.

O2-02: Elapsed Time Reset

- Use constant O2-02 to reset elapsed time.

O2-03: Elapsed Time Select

Setting	Function
O2-03=0 (Initial setting)	The elapsed time started to be counted after power is on.
O2-03=1	The elapsed time started to be counted after RUN.

O2-04: Stackable Inverter Model

- This is the model number to be displayed.

O2-06: MODE Key Hold Time

- Use constant O2-06 to set the time it takes to press MODE key to transfer from one of four modes to another mode. (This has to be done in STOP mode)
- Initial setting=5 sec, setting range: 2~10 sec.

O2-07: RUN/STOP Key Hold Time

- Use constant O2-07 to set the time it takes to press RUN/STOP key to activate its function.
- Initial setting=2 sec, setting range: 2~10 sec.

O2-08: Power ON Auto Run Select

- Use constant O2-08 to select to auto run manually or automatically.

Setting	Function
O2-08=0	Auto Run is active when pressing Run/STOP key
O2-08=1 (Initial setting)	Auto Run is active when the power is on.

O2-09: LCD Display Idle Time Set

- When O2-09=0, Display Idle Function is disabled.
- Use constant O2-09 to set the idle time when the keypad is not operated and all the LCD Display and LED Indicators of the Stackable Inverter entering the idle mode which only RUN/STOP indicator is active.
- Once any key on the panel is pressed, it will return to the display before Idle status.
- Initial setting=10 min, setting range: 0~60 min.

U Group (Monitor):
U1 Group (Monitor)

U1-01: AC IN Voltage

- Use U1-01 to monitor the current voltage value of AC IN power in unit of 0.1V.

U1-02: AC IN Current

- Use U1-02 to monitor the current value of AC IN power in unit of 0.1A.

U1-03: AC OUT Voltage

- Use constant U1-03 to monitor AC OUT voltage value in unit of 0.1V.

U1-04: AC OUT Current

- Use constant U1-04 to monitor AC OUT current value in unit of 0.1A .

U1-05: Battery Voltage

- Use constant U1-05 to monitor the battery voltage in unit of 0.1V.

U1-06: Battery Ripple Voltage

- Use constant U1-06 to monitor the battery ripple voltage in unit of 0.1V.

U1-07: Battery Current

- Use constant U1-07 to monitor battery current value in unit of 0.1A.

U1-08: Control Mode

- Use constant U1-08 to monitor the current control mode (MODE 1, MODE 2, MODE 3 or MODE 4)

U1-09: Operation Status

- There are 12 digits to account for each operation status. Please see NOTE 1 in Chapter 5.

U1-10: Aux-Relay Status

- Use constant U1-10 to monitor the ON/OFF status of 3 sets of Aux-Relay (RY1, RY2, RY3). Please see NOTE 2 in Chapter 5.

U1-11: Elapsed Time

- Use constant U1-11 to monitor the elapsed time after power ON (O2-03=0) or after RUN (O2-03=1) in unit of 1 hour.

U1-12: Battery Temperature Sensor

- Use constant U1-12 to monitor the temperature that has been detected by Battery Temperature Sensor (BTS-3) in unit of 1°C.

U1-13: CPU ID1

- Use constant U1-13 to check the software version 1.

U1-14: CPU ID2

- Use constant U1-14 to check the software version 2.

U1-15: Solar Charger Status

- Use constant U1-15 to monitor solar charger status after solar module is connected to the extension port (Port C).

U1-16: Solar Supply Current

- Use constant U1-16 to monitor the solar supply current value in unit of 0.1A.

U1-17: Solar Supply Power

- Use constant U1-17 to monitor the solar supply power value in unit of 1W.

U1-18: Solar Amp-Hours

- Use constant U1-18 to monitor solar Amp-Hours value in unit of 1AH.

U1-19: Solar Total Amp-Hours

- Use constant U1-19 to monitor solar total Amp-Hours value in unit of 1AH.

U2 Group (Fault Trace)

U2-01: Current Fault

- Use constant U2-01 to monitor the current fault that results in “Stackable Inverter” stopping operating.

U2-02: Last Fault

- Use constant U2-02 to monitor the last fault that has been recorded.

U2-03: AC IN Voltage

- Use constant U2-03 to monitor the AC input voltage value in unit of 0.1V when the current fault occurs.

U2-04: AC IN Current

- Use constant U2-04 to monitor the AC input current value in unit of 0.1A when the current fault occurs.

U2-05: AC OUT Voltage

- Use constant U2-05 to monitor the AC output voltage value in unit of 0.1V when the current fault occurs.

U2-06: AC OUT Current

- Use constant U2-06 to monitor the AC output current value in unit of 0.1A when the current fault occurs.

U2-07: Battery Voltage

- Use constant U2-07 to monitor the battery voltage value in unit of 0.1V when the current fault occurs.

U2-08: Battery Ripple Volt

- Use constant U2-08 to monitor the battery ripple voltage in unit of 0.1V when the current fault occurs.

U2-09: Battery Current

- Use constant U2-09 to monitor the battery current value in unit of 0.1A when the current fault occurs.

U2-10: Control Mode

- Use constant U2-10 to monitor what the control mode (MODE 1, MODE 2, MODE 3 or MODE 4) is when the current fault occurs.

U2-11: Operation Status

- Use constant U2-11 to monitor 12 digits which account for each operation status when the current fault occurs. Please see NOTE 1 in Chapter 5.

U2-12: Aux-Relay Status

- Use constant U2-12 to monitor the ON/OFF status of 3 sets of Aux-Relay (RY1, RY2, RY3) when the current fault occurs. Please see NOTE 2 in Chapter 5.

U2-13: Elapsed Time

- Use constant U2-13 to monitor the elapsed time after power ON (O2-03=0) or after RUN (O2-03=1) in unit of 1 hour when the current fault occurs.

U2-14: Solar Charger Status

- Use constant U2-14 to monitor solar charger status when the current fault occurs. This constant is only visible when extension port is connected to solar module.

U2-15: Solar Charge Current

- Use constant U2-15 to monitor the solar charge current value in unit of 0.1A when the current fault occurs.

U2-16: Solar Supply Power

- Use constant U2-16 to monitor the solar supply power value in unit of 1W when the current fault occurs.

U2-17: Solar Amp-Hours

- Use constant U2-17 to monitor solar Amp-Hours value in unit of 1AH when the current fault occurs.

U2-18: Solar Total Amp-Hours

- Use constant U2-18 to monitor solar total Amp-Hours value in unit of 1AH when the current fault occurs.

U2-26: Battery Temperature Sensor

- Use constant U2-26 to monitor the current temperature that has been detected by Battery Temperature Sensor (BTS-3) in unit of 1°C when the current fault occurs.

U3 Group (Fault History)

U3-01: Last Fault

- Use constant U3-01 to monitor the latest fault stored in the software.

U3-02: Fault Message 2

- Use constant U3-02 to monitor the most recent second fault stored in the software.

U3-03: Fault Message 3

- Use constant U3-03 to monitor the most recent third fault stored in the software.

U3-04: Fault Message 4

- Use constant U3-04 to monitor the most recent fourth fault stored in the software.

U3-05: Elapsed Time 1

- Use constant U3-05 to monitor the elapsed time before the latest fault occurs.

U3-06: Elapsed Time 2

- Use constant U3-06 to monitor the elapsed time before the most recent second fault occurs.

U3-07: Elapsed Time 3

- Use constant U3-07 to monitor the elapsed time before the most recent third fault occurs.

U3-08: Elapsed Time 4

- Use constant U3-08 to monitor the elapsed time before the most recent fourth fault occurs.

Chapter 7 Trouble Shooting Table

- Proceed as follows for a quick detection of common faults.
- DC loads must be disconnected from the batteries and the AC loads must be disconnected from the INVERTER before the INVERTER and/or battery charger (AC CHARGER) is tested.
- Consult your Power Master dealer if the fault cannot be resolved.

Problem or Error message	Cause	Solution
The “Stackable Inverter” fails to operate when power on.	The battery voltage is too high or too low.	Ensure that the battery voltage is within the correct value range.
<div>‘Udc-UV’ Battery under volt</div> <div>‘ ’: blink</div>	The battery voltage is low.	Charge the battery or check the battery connections.
<div>Udc-UV Battery under volt</div>	The “Stackable Inverter” cuts out because the battery voltage is too low.	Charge the battery or check the battery connections.
<div>‘OL’ Inverter OverLoad</div> <div>‘ ’: blink</div>	The load on the inverter of “Stackable Inverter” is higher than the normal load.	Reduce the load.
<div>OL Inverter OverLoad</div>	The INVERTER of “Stackable Inverter” cuts out due to excessive load.	Reduce the load.
<div>‘OH’ Heatsink Max Temp.</div> <div>‘ ’: blink</div>	The ambient temperature is too high, or the load is excessive.	Place the “Stackable Inverter” in a cool and well-ventilated room, or reduce the load.

<div>OH</div> <div>Heatsink Max Temp.</div>	The ambient temperature is too high, or the load is excessive.	Place the “Stackable Inverter” in a cool and well-ventilated room, or reduce the load.
<div>‘Udc-ripple’</div> <div>Volt Ripple Exceeds</div> <div>‘ ’: blink</div>	Voltage ripple on the DC input exceeds 1.25Vrms	Check the battery cables and terminals. Check the battery capacity; increase it if necessary.
<div>Udc-ripple</div> <div>Volt Ripple Exceeds</div>	The INVERTER of “Stackable Inverter” cuts out as a result of excessive voltage ripple on the DC input	Install batteries with a higher capacity. Use shorter and/or thicker battery cables and reset the Stackable Inverter (Power OFF and ON again).
<div>‘Udc-OV’</div> <div>Battery over voltage.</div> <div>‘ ’: blink</div>	Battery charger is not in normal charging status to cause battery voltage too high.	Replace the “Stackable Inverter”.
<div>Udc-OV</div> <div>Battery over voltage.</div>	Incorrect battery voltage connection (12V system but connected to 24V battery)	Recheck if the Stackable Inverter and the battery voltage is matched.
<div>‘Idc-OC’</div> <div>Over current.</div> <div>‘ ’: blink</div>	The actual charge current is 1.5 times larger than the set current value (D1-08) when AC CHARGER is operating.	Stop the Charge mode of the “Stackable Inverter”.
<div>Idc-OC</div> <div>Over current.</div>		Repair or replace the “Stackable Inverter”.

<div>‘Bat-NG’ Battery Fault</div> <div>‘ ’: blink</div>		
<div>Bat-NG Battery Fault</div>	<p>The charging time of <u>AC CHARGER</u> has been over 10 hours and remains in Bulk Charge mode. (D1-09=1) shows the battery is at fault.</p>	<p>Replace the battery banks.</p>
<p>The charger is not functioning</p>	<p>The AC IN voltage or frequency is out of range.</p>	<p>Ensure that the AC IN voltage is within the range 220V system: 180VAC~260VAC 110V system: 90VAC~130VAC And that the frequency matches the setting.</p>
	<p>“Stackable Inverter” internal circuit breaker has tripped.</p>	<p>Reset the internal circuit breaker.</p>
<p>The battery is not being charged fully.</p>	<p>Incorrect charging current.</p>	<p>Set the charging current at between $(0.1\sim0.2) \times$ battery capacity.</p>
	<p>A defective battery connection.</p>	<p>Check the battery terminals.</p>
	<p>The absorption voltage has been set an incorrect value.</p>	<p>Adjust the absorption voltage to the correct value.</p>
	<p>The float voltage has been set to an incorrect value.</p>	<p>Adjust the float voltage to the correct value.</p>
	<p>The internal DC fuse is defective</p>	<p>“Stackable Inverter” is damaged.</p>
<p>The battery is overcharged.</p>	<p>The absorption voltage has been set to an incorrect value.</p>	<p>Adjust the absorption voltage to the correct value.</p>
	<p>The float voltage has been set to an incorrect value.</p>	<p>Adjust the float voltage to the correct value.</p>

The battery is overcharged.	The battery is too small.	Reduce the charging current or use a battery with a higher capacity.
	A defective battery.	Replace the battery.
	The battery is too hot.	Connect a Battery Temperature Sensor (BTS-3)
Battery charge current drop to 0 A when the absorption voltage is reached.	Battery over temperature ($> 50^{\circ}\text{C}$)	<ol style="list-style-type: none"> 1. Allow battery to cool down. 2. Place battery in a cool environment. 3. Check for shorted cells.
	Battery Temperature Sensor (BTS-3) is faulty	<ol style="list-style-type: none"> 1. Unplug Battery Temperature Sensor (BTS-3) from “Stackable Inverter” and power off the “Stackable Inverter” then wait 5 seconds and power on again. 2. If the “Stackable Inverter” AC CHARGE normally, the BTS-3 is faulty and needs to be replaced.